

**SPA START-UP WITH SPA FROG SYSTEM
300-500 GALLONS**

START UP

Remove the filter cartridge and begin filling the spa by inserting a garden hose into the hole where the cartridge sits. Add 3 capfuls of Stain & Scale Control while filling. Fill spa to water line or just above highest jet. Adjust PH, Alkalinity and Calcium Hardness. Set temp control to 100-102 and let the spa heat up. While the spa is heating, adjust your cartridges: for the Blue Mineral Cartridge set wide open on setting #6, for Yellow Bromine Cartridge set wide open on setting #4 then place the Spa Frog Floating System into the water and hold under water until the all air is out.

MAINTENANCE

Every 4 months replace mineral cartridge
Every 4 or 5 weeks replace yellow bromine cartridge

WEEKLY

Every Sunday:
Test weekly with test strips adjust PH, Alkalinity and Calcium Hardness accordingly
Add 3 caps of Stain & Scale
Add 1 cap of Spa Shock

DO NOT MOVE DIVERTERS WHEN JETS ARE BLOWING AT FULL FORCE



BioGuard.
pool care



609-655-0990 800-300- SPLASH

Fax 609-655-0223

www.poolnspaplace.com